



Child safety button, must be pressed and held down while pressing hot tap button

Has 2 functions:

1. Hot tank no/off button. When you see the thermometer start to flash hot tank is heating.
2. when in mode function this button acts as the + button to increase hot and cold temp and change hour and min on clock

Has 2 functions:

1. Compressor no/off button. When you see the snowflake flashing, water is cooling.
2. when in mode function this button acts as the - button to decrease hot and cold temp and change hour and min on clock

Mode button

1. Press once hot temp will flash and allow you to change the temperature using the 2 middle grey buttons
2. press twice cold temp will flash and allow you to change the temperature using the 2 middle grey buttons
3. press a third time hour digit will flash to change the time using the 2 middle grey buttons
4. press a fourth time minute digit will flash to change the time using the 2 middle grey buttons
5. Press a fifth time to set temperature and time set.